Lista recambios

Posición	Artículo nº	Descripción	Cantidad
11	05719	LOCKING PIN 5X14	2 ST
20	06696	BASE PLATE H=24.0	1 ST
30	05100	GASKET-BASE PLATE	1 ST
40	06080	HEX.HEAD SCREW M10X30	20 ST
50	07899	GASKET-LOWER VALVE PLATE ø80	2 ST
60	06694	VALVE PLATE CPL. ø70/75/80 FOR HG(X)5	2 ST
	50702	VALVE PLATE CPL. ø70/75/80 FOR HGX5 R134a	2 ST
70	06484	GASKET-UPPER VALVE PLATE FOR HG(X)5	2 ST
	06486	GASKET-UPPER VALVE PLATE FOR HGX5 R134a	2 ST
100	07940	DECOMPRESSION VALVE M24X1,5	2 ST
110	05791	SEAL RING 27,8x24,2x2	2 ST
120	07855	PRESSURE BALANCE VALVE CPL.	2 ST
170	03643	CYLINDER COVER STANDARD FOR HG(X)5	1 ST
	33388	CYLINDER COVER STANDARD FOR HGX5 R134a	1 ST
175	03644	CYLINDER COVER F.CR FOR HG(X)5	1 ST
	33388	CYLINDER COVER STANDARD FOR HGX5 R134a	1 ST
178	05514	LOCKING SCREW 1/8"NPTF	2 ST
180	06828	HEX.HEAD SCREW M10X75	23 ST
185	05492	CYLINDER HEAD SCREW M10X75 FOR HG(X)5	3 ST
	06828	HEX.HEAD SCREW M10X75 FOR HGX5 R134a	3 ST
190	05986	O-RING ø45,69X2,62 GREEN ONLY FOR HG(X)5	1 ST
195	06495	LOCKING SCREW M45X1,5 ONLY FOR HG(X)5	1 ST
210	05083	GASKET-VALVE FLANGE	1 ST
220	06034	HEX.HEAD SCREW M10X65	2 ST
270	05993	PISTON PIN ø20X13X66	4 ST
280	05569	CIRCLIP 20X1 DIN 472	8 ST
290	06369	DOUBLE BEVEL OIL CONT.RING 80	4 ST
295	06368	OIL SCRAPER RING PISTON 80	4 ST
300	06367	TAPERED COMPR.RING PIS.80 CHR.	4 ST
330	07128	SHUT-OFF VALVE (AL)	1 ST
331	05784	CAP NUT M22X1,5	1 ST
332	05789	CAP NUT 7/16"UNF	1 ST
333	05514	LOCKING SCREW 1/8"NPTF	1 ST
340	05067	GASKET RING 42X34X1	1 ST
350	05313	SOLDERED BUSH ø35	1 ST
360	04329	FLANGE OVAL 16MM	1 ST
371	05797	CAP NUT M36X1,5	1 ST
372	05800	SCREW-IN FITTING DIN 8906	1 ST
	05545	SEALING CAP 7/16"UNF	1 ST
	05528	UNION NUT 7/16"UNF	1 ST
374	05112	GASKET RING 75X61X1,0	1 ST
375	05798	SOLDERED BUSH ø54	1 ST
376	05785	SQUARE FLANGE (NS50)	1 ST
377	05415	HEX.HEAD SCREW M16X50	4 ST
380	05489	CYLINDER HEAD SCREW M10X35	2 ST
420	06573	ADJUSTING SCREW M10X0,75	1 ST
430	05764	STEEL BALL ø6,35	1 ST
440	06651	PRESSURE SPRING-OIL OV.PRESSU.	1 ST
460	06951	OIL PUMP COMPLETE	1 ST
465	06580	O-RING ø82,22X2,62	1 ST
470	05094	GASKET-F.OIL P.+REAR BEAR.FL.	1 ST
480	05431	HEX.HEAD SCREW M8X55	8 ST
500	05342	SEAL RING 27x22x2	3 ST
504	07566	HEATER INS.140W 230V AC	1 ST
	07570	HEATER INS.140W 110-130V,SP.V. SPECIAL VERSION	1 ST
508	05801	LOCKING SCREW 1/4"NPTF	1 ST
510	06348	LOCKING SCREW M22X1,5	1 ST
520	05514	LOCKING SCREW 1/8"NPTF	2 ST
527	05801	LOCKING SCREW 1/4"NPTF	1 ST
530	05752	T-PIECE WITH SCHRADER CONNECT.	1 ST

532	05514	LOCKING SCREW 1/8"NPTF	1 ST
540	05541	SCREW-IN ANGLE PIECE DIN 8906	1 ST
570	06001	SIGHT GLASS ø62	1 ST
580	05402	HEX.HEAD SCREW M6X16	4 ST
590	05153	O-RING ø34,59X2,62	1 ST
600	06236	RING SCREW M12	1 ST
630	06589	NON-RETURN DISC	1 ST
650	06594	SEAT RING	1 ST
750	06620	HEX.HEAD SCREW M10X25	6 ST
760	06653	O-RING ø238X5	1 ST
770	05691	CYLINDER PIN 6M6x15	1 ST
790	06654	FEATHER KEY A12X8X50 DIN 6885	1 ST
800	04425	DISC ø50X12,5X8	1 ST
810	05666	SPRING WASHER B12	1 ST
820	06836	HEX.HEAD SCREW M12X40/PREC.	1 ST
835	06833	BLANK FLANGE	1 ST
840	05402	HEX.HEAD SCREW M6X16	3 ST
850	06218	O-RING ø32,99X2,62	1 ST
1010	06644	CYLINDER HEAD SCREW M10X60	8 ST
1020	06918	FEATHER KEY A5X5X60 DIN 6885	1 ST
1022	50047	THREADED PIN M8X16/PREC.	1 ST
1030	03734	MOTOR FOOT	1 ST
1040	05421	HEX.HEAD SCREW M8X25	2 ST
1050	06747	TERMINAL BOARD	1 ST
1055	05073	INSULATION FOIL NPN 5, PIERCED	1 ST
1060	06559	GASKET-TERMINAL BOARD	1 ST
1070	06244	HEX.HEAD SCREW M8X30	10 ST
1100	06061	HEX.HEAD SCREW M6X12 - A2	1 ST
1120	06043	LOCK WASHER S M6	12 ST
1121	05193	LOCK WASHER S M6 - A2	1 ST
1125	05654	LOCK WASHER S M8 - A2	8 ST
1130	05741	BRIDGE ELECTRIC CONNECTION	3 ST
1150	05629	HEX.HEAD NUT M8 - A2	6 ST
1160	06626	HEX.HEAD SCREW M6X10	6 ST
1175	07921	ROTOR 15KW FOR HG(X)5/945-4	1 ST
	07922	ROTOR 18,5KW	1 ST
	70075	ROTOR 18,5KW (OPTIMIZED) SEULEMENT POUR 230/400D/S 60HZ FOR HG(X)5/945-4 S	1 ST
1180	06709	SPACER SLEEVE 15KW+18,5KW	1 ST
1190	05983	FILTER SUCTION SIDE	1 ST
1210	05111	GASKET RING 81,5X60X1	2 ST
1220	06155	HEX.HEAD SCREW M16X100	4 ST
1520	08874	SET-FIXING PARTS	1 ST
		------ ASSEMBLY KITS ------	
2000	08851	SET-VALVE PLATE FOR HG(X)5	2 ST
	80719	SET-VALVE PLATE FOR HGX5 R134a	2 ST
2020	08384	SET-OIL PUMP F.DELTA-P SWITCH	1 ST
2030	80106	SET-PISTON ø80 (OPTIMIZED)	4 ST
2040	08828	SET-PISTON-CONN.(80,OPTIM.)	4 ST
2050	08853	SET-CRANKSHAFT 47 STROKE	1 ST
2060	08082	SET-SHUT-OFF VALVE NS32 (AL)	1 ST
2070	08087	SET-SHUT-OFF VALVE NS50	1 ST
2080	08130	SET-SIGHT GLASS ø62	1 ST
2090	08961	SET-GASKETS NOT SHOWN	1 ST
2100	08307	SET-CONNECTING ROD	4 ST
2120	80175	SET-BEARING BUSH HA/HG4+5	1 ST
2130	08968	SET-MOT.CASI.+STAT.15KW Y/YY FOR HG(X)5/945-4	1 ST
	80274	SET-MOT.CASI.+STAT.15KW Δ/Y FOR HG(X)5/945-4 230/400V 50HZ (280/460V 60Hz) FOR SPECIAL VOLTAGE	1 ST
	80142	SET-MOT.CASI.+STAT.15KW Δ/Y FOR HG(X)5/945-4 230/400V 60HZ FOR SPECIAL VOLTAGE	1 ST
	08969	SET-MOT.CASI.+STAT.18,5KW Y/YY FOR HG(X)5/945-4 S	1 ST
	80278	SET-MOT.CASI.+STAT.18,5KW Δ/Y FOR HG(X)5/945-4 S 230/400V 50HZ (280/460V 60Hz) FOR SPECIAL VOLTAGE	1 ST

	80144	SET-MOT.CASI.+STAT.18,5KW Δ/Y FOR HG(X)5/945-4 S 230/400V 60HZ FOR SPECIAL VOLTAGE	1 ST
2150	80555	SET-STATOR 15KW Y/YY -fr.AS019 FOR HG(X)5/945-4	1 ST
	80562	SET-STATOR 15KW Δ/Y -fr.AS019 FOR HG(X)5/945-4 230/400V 50HZ (280/460V 60HZ) FOR SPECIAL VOLTAGE	1 ST
	80566	SET-STATOR 15KW Δ/Y -fr.AS019 FOR HG(X)5/945-4 230/400V 60HZ FOR SPECIAL VOLTAGE	1 ST
	80557	SET-STATOR 18,5KW Y/YY-f.AS019 FOR HG(X)5/945-4 S	1 ST
	80564	SET-STATOR 18,5KW Δ/Y-fr.AS019 FOR HG(X)5/945-4 S 230/400V 50HZ (280/460V 60HZ) FOR SPECIAL VOLTAGE	1 ST
	80568	SET-STATOR 18,5KW Δ/Y-fr.AS019 FOR HG(X)5/945-4 S 230/400V 60HZ FOR SPECIAL VOLTAGE	1 ST
2160	08949	SET-TERMINAL BOARD	1 ST
2170	80152	SET-TERMINAL BOX / PA,BLUE	1 ST
	80153	SET-TERMINAL BOX / PA,BLACK SPECIAL VERSION	1 ST
	80476	SET-TERM.BOX / PA,BLUE F.BCM WITH INSPECTION WINDOW FOR BCM	1 ST
2180	80079	SET-FRONT BEARING FLANGE	1 ST
2190	08102	SET-MOTOR PROT.MP10,AC 230V	1 ST
	08103	SET-MOTOR PROT.MP10,DC 24V *EX SPECIAL VERSION	1 ST
2210	08426	SET-OILS.HEAT.140W 230V AC	1 ST
	08430	SET-OILS.HEAT.140W 110-130V,SP SPECIAL VERSION	1 ST
2220	08456	SET-OIL STRAINER	1 ST
		------- ACCESSORIES ------- SU+CR+(SEA.)WC.CYLINDER COVER FOR R134a NOT ALLOWED !	
3000	08981	SET-START UNL.SU92 230V AC	1 ST
3010	03649	WC.CYLINDER COVER F.SU(BUSH)	1 ST
3020	06484	GASKET-UPPER VALVE PLATE	1 ST
3030	05454	HEX.HEAD SCREW M10X85	10 ST
3040	06276	CYLINDER HEAD SCREW M10X85	3 ST
3050	05738	LOCKING SCREW R 1/2"	2 ST
3060	05526	LOCKING SCREW R 1/2"	1 ST
3070	08953	SET-WC.CYLINDER COVER	1 ST
	80647	SET-SEA.WC.CYL.COVER	1 ST
	80646	SET-WC.CYLINDER COVER F.CR92	1 ST
	80650	SET-SEA.WC.CYL.COVER F.CR92	1 ST
	08976	SET-WC.CYLINDER COVER F.SU92	1 ST
	80649	SET-SEA.WC.CYL.COVER F.SU92	1 ST
3100	08821	SET-SU/CR92 230V AC	1 ST
3110	07848	VALVE BODY AL/LR92	1 ST
3111	05986	O-RING ø45,69X2,62 GREEN	1 ST
3112	05143	DISC ø30X16X2,0	1 ST
3113	05885	KNURLED NUT M15X1 WITH O-RING	1 ST
3120	07527	SOLENOID COIL 230V AC	1 ST
3200	08948	SET-CAP.REG.CR92 230V AC	1 ST
3210	03644	CYLINDER COVER F.CR	1 ST
3230	05492	CYLINDER HEAD SCREW M10X75	3 ST
3250	08140	SET-BOCK-BCM 2000	1 ST
3260	06920	TAPP.SCREW W.COUNT.HEADC3.5X13	3 ST
3270	06950	BOCK-BCM 2000, AC 230V ±10%	1 ST
3275	06945	BASE PLATE SNAP-ON MOUNTING	1 ST
3280	80655	SET-BOCK-BCM 2000 /INCL.D-P	1 ST
3300	08821	SET-SU/CR92 230V AC	1 ST
3310	07848	VALVE BODY AL/LR92	1 ST
3311	05986	O-RING ø45,69X2,62 GREEN	1 ST
3312	05143	DISC ø30X16X2,0	1 ST
3313	05885	KNURLED NUT M15X1 WITH O-RING	1 ST
3320	07527	SOLENOID COIL 230V AC	1 ST
3400	80045	SET-ADDIT.VENTILA.ø312/HG4+5+6	1 ST
3410	06808	VENTILATOR CPL.ø312 230/400V	1 ST
3415	80196	SET-ASSEMBLY KIT F.IMP. HG4-6	1 ST

3420	06805	HOLDER F.ADDITIONAL VENTILATOR	2 ST
3430	06809	SPACING ROLLER ø20X9	2 ST
3440	06278	HEX.HEAD SCREW M10X80	4 ST
3450	05445	HEX.HEAD SCREW M10X25	4 ST
3460	05646	DISC B10,5	12 ST
3470	05665	SPRING WASHER B10	4 ST
3480	05630	HEX.HEAD NUT M10	4 ST
3500	08920	SET-OIL PRESSURE SAFETY SWITCH	1 ST
3510	05251	REFFLEX-HOSE LINE,DN 2MM CONSISTING OF REFF.HOSE 50246 + 2x SEAL RING(7/16") 06104	1 ST
3520	05253	REFFLEX HOSE LINE,DN 2MM CONSISTING OF REFF.HOSE 50248 + 2x SEAL RING(7/16") 06104	1 ST
3600	07946	SHUT-OFF VALVE 1/4"NPTF-7/16"	1 ST
3700	80461	SET-OIL PRESS.SENSOR/MP10	1 ST
	80275	SET-OIL PRESS.SENSOR/BCM2000	1 ST
3710	60014	DELTA-P II SWITCH PART F.MP10	1 ST
	06989	INT250 SWITCH PART F.BCM 2000	1 ST
3720	50225	DELTA-P/INT250 SCREW-IN PART	1 ST
3730	05724	SEAL RING 26x20x1,5	1 ST
3750	06947	OIL TEMP.SENSOR CPL.1/8"NPTF	1 ST
3800	08921	SET-THERM PROT.TH.1/8"NPTF	1 ST
3900	80260	SET-ADAPT.F.SHUT-OFF VALVE	1 ST
3910	80465	SET-START UNL.BOCK-ESS 63	1 ST
3990	80594	SET-EFCe A1-A6 15,0KW/18,5e WITHOUT PRESSURE TRANSDUCER FOR HG(X)5/945-4	1 ST
	80629	SET-EFCe A1-A6 15,0KW/18,5e WITH PRESSURE TRANSDUCER FOR HG(X)5/945-4	1 ST
	80596	SET-EFCe A1-A6 18,5KW/30,0e WITHOUT PRESSURE TRANSDUCER FOR HG(X)5/945-4 S	1 ST
	80631	SET-EFCe A1-A6 18,5KW/30,0e WITH PRESSURE TRANSDUCER FOR HG(X)5/945-4 S	1 ST
3991	80698	SET-HEAT-RESISTANT BACK WALL FOR HG(X)5/945-4	1 ST
	80696	SET-HEAT-RESISTANT BACK WALL FOR HG(X)5/945-4 S	1 ST
3999	02279	REFR.MACH.OIL SP46 / 1 LTR.CAN	1 ST
	02280	REFR.MACH.OIL SP46 / 5 LTR.CAN	1 ST
	02281	REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN ONLY FOR R22-COMPRESSORS!	1 ST
	02282	REFR.MACH.OIL SE55 / 1 LTR.CAN	1 ST
	02283	REFR.MACH.OIL SE55 / 5 LTR.CAN	1 ST
	02284	REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS!	1 ST