

Lista recambios

Posición	Artículo nº	Descripción	Cantidad
20	06696	BASE PLATE H=24.0	1 ST
30	05100	GASKET-BASE PLATE	1 ST
40	06080	HEX.HEAD SCREW M10X30	20 ST
50	06760	GASKET-LOWER VALVE PLATE ø70	3 ST
60	07845	VALVE PLATE CPL. ø70/75/80 FOR HG(X)7	3 ST
	50703	VALVE PLATE CPL. ø70/75/80 FOR HG(X)7 R134a	3 ST
70	06484	GASKET-UPPER VALVE PLATE FOR HG(X)7	3 ST
	06486	GASKET-UPPER VALVE PLATE FOR HG(X)7 R134a	3 ST
100	07940	DECOMPRESSION VALVE M24X1,5	3 ST
110	05791	SEAL RING 27,8x24,2x2	3 ST
120	07855	PRESSURE BALANCE VALVE CPL.	2 ST
160	05492	CYLINDER HEAD SCREW M10X75 FOR HG(X)7	6 ST
	06828	HEX.HEAD SCREW M10X75 FOR HG(X)7 R134a	6 ST
170	03643	CYLINDER COVER STANDARD FOR HG(X)7	1 ST
	33388	CYLINDER COVER STANDARD FOR HG(X)7 R134a	1 ST
175	03644	CYLINDER COVER F.CR FOR HG(X)7	2 ST
	33388	CYLINDER COVER STANDARD FOR HG(X)7 R134a	2 ST
178	05514	LOCKING SCREW 1/8"NPTF	3 ST
180	06828	HEX.HEAD SCREW M10X75	33 ST
190	05986	O-RING ø45,69X2,62 GREEN ONLY FOR HG(X)6	2 ST
195	06495	LOCKING SCREW M45X1,5 ONLY FOR HG(X)6	2 ST
210	05097	GASKET RING 70X54X1,0	1 ST
220	06684	HEX.HEAD SCREW M12X85	4 ST
270	07214	PISTON PIN ø20X13X60	6 ST
280	05569	CIRCLIP 20X1 DIN 472	12 ST
290	06366	DOUBLE BEVEL OIL CONT.RING 70	6 ST
295	06365	OIL SCRAPER RING PISTON 70	6 ST
300	06364	TAPERED COMPR.RING PIS.70 CHR.	6 ST
331	05796	CAP NUT M27X2	1 ST
332	05800	SCREW-IN FITTING DIN 8906	1 ST
	05545	SEALING CAP 7/16"UNF	1 ST
	05528	UNION NUT 7/16"UNF	1 ST
340	05113	GASKET RING 52X38X1,0	1 ST
350	06009	SOLDERED BUSH ø42	1 ST
360	05787	SQUARE FLANGE (NS32-38)	1 ST
371	05797	CAP NUT M36X1,5	1 ST
372	05800	SCREW-IN FITTING DIN 8906	1 ST
	05545	SEALING CAP 7/16"UNF	1 ST
	05528	UNION NUT 7/16"UNF	1 ST
374	05112	GASKET RING 75X61X1,0	1 ST
375	05798	SOLDERED BUSH ø54	1 ST
376	05785	SQUARE FLANGE (NS50)	1 ST
377	05415	HEX.HEAD SCREW M16X50	4 ST
380	05463	HEX.HEAD SCREW M12X50	4 ST
460	07788	OIL PUMP COMPLETE	1 ST
470	05094	GASKET-F.OIL P.+REAR BEAR.FL.	1 ST
480	05421	HEX.HEAD SCREW M8X25	6 ST
485	05426	HEX.HEAD SCREW M8X40	2 ST
490	06723	OIL STRAINER	1 ST
500	05342	SEAL RING 27x22x2	3 ST
504	07566	HEATER INS.140W 230V AC	1 ST
	07570	HEATER INS.140W 110-130V,SP.V. SPECIAL VERSION	1 ST
505	50055	LOCKING SCREW W.MAGNET	1 ST
508	05801	LOCKING SCREW 1/4"NPTF	1 ST
510	06348	LOCKING SCREW M22X1,5	1 ST
520	05514	LOCKING SCREW 1/8"NPTF	5 ST
527	05801	LOCKING SCREW 1/4"NPTF	2 ST
530	05752	T-PIECE WITH SCHRADER CONNECT.	1 ST
532	05514	LOCKING SCREW 1/8"NPTF	1 ST
540	05541	SCREW-IN ANGLE PIECE DIN 8906	1 ST

570	06082	SIGHT GLASS ø60	2 ST
580	05402	HEX.HEAD SCREW M6X16	6 ST
590	06218	O-RING ø32,99X2,62	2 ST
600	06237	RING SCREW M16	1 ST
625	07803	NON-RETURN VALVE ø12 CPL.	1 ST
740	04273	REAR BEARING FLANGE	1 ST
750	06080	HEX.HEAD SCREW M10X30	8 ST
755	06034	HEX.HEAD SCREW M10X65	2 ST
765	06878	GASKET-REAR BEARING FLANGE	1 ST
770	05691	CYLINDER PIN 6M6x15	1 ST
790	06879	FEATHER KEY A9,56X8X50	1 ST
800	04425	DISC ø50X12,5X8	1 ST
810	05666	SPRING WASHER B12	1 ST
820	06836	HEX.HEAD SCREW M12X40/PREC.	1 ST
1000	04274	COVER SUCTION SIDE	1 ST
1010	06881	HEX.HEAD SCREW M10X110	8 ST
1015	06882	HEX.HEAD SCREW M10X170	2 ST
1017	06883	O-RING ø278,77X5,33	1 ST
1020	50060	THREADED PIN M8X20/PREC.	2 ST
1022	06880	FEATHER KEY A4,63X5X70	1 ST
1030	06877	MOTOR FOOT	1 ST
1040	05091	COUNTERSUNK SCREW M10X35	2 ST
1050	06864	TERMINAL BOARD	1 ST
1055	05074	INSULATION FOIL NPN 5, PIERCED	1 ST
1060	06876	GASKET-TERMINAL BOARD FOR SERIAL VOLTAGE	1 ST
	06876	GASKET-TERMINAL BOARD FOR SPECIAL VOLTAGE 230/400 Δ/Y 50/60HZ (+ 280/460 Δ/Y 60HZ)	2 ST
1062	06908	INTERMEDIATE PLATE FOR SPECIAL VOLTAGE 230/400 Δ/Y 50/60HZ (+ 280/460 Δ/Y 60HZ)	1 ST
1070	05447	HEX.HEAD SCREW M10X35 FOR SERIAL VOLTAGE	10 ST
	05458	HEX.HEAD SCREW M10X50 FOR SPECIAL VOLTAGE 230/400 Δ/Y 50/60HZ (+ 280/460 Δ/Y 60HZ)	10 ST
1080	03964	TERMINAL BOX CPL./ST.BLUE SERIAL	1 ST
	04465	TERMINAL BOX CPL./ST.BLUE-BCM WITH INSPECTION WINDOW FOR BCM	1 ST
1090	06872	GASKET-TERMINAL BOX	1 ST
1100	06061	HEX.HEAD SCREW M6X12 - A2	4 ST
1103	05418	HEX.HEAD SCREW M8X16 - A2	1 ST
1110	05664	SERRATED WASHER A6,4	4 ST
1120	06043	LOCK WASHER S M6	6 ST
1123	05654	LOCK WASHER S M8 - A2	1 ST
1125	05654	LOCK WASHER S M8 - A2	8 ST
1130	05916	BRIDGE FOR TERMINAL BOARD	3 ST
1150	05629	HEX.HEAD NUT M8 - A2	6 ST
1151	06380	GROUND CABLE	2 ST
1160	06626	HEX.HEAD SCREW M6X10	6 ST
1170	06096	STATOR 29KW Δ/YYY FOR HG(X)7/1620-4	1 ST
	06097	STATOR 33KW Δ/YYY FOR HG(X)7/1620-4 S	1 ST
1175	06092	ROTOR 22KW/25KW/29KW FOR HG(X)7/1620-4	1 ST
	06093	ROTOR 33KW FOR HG(X)7/1620-4 S	1 ST
1177	06708	SPACER SLEEVE 11KW+22KW+29KW FOR HG(X)7/1620-4	1 ST
1190	05983	FILTER SUCTION SIDE FOR HG(X)7	1 ST
	50850	FILTER SUCTION SIDE F.R134a FOR HG(X)7 R134a	1 ST
1210	05111	GASKET RING 81,5X60X1 FOR HG(X)7	2 ST
	05111	GASKET RING 81,5X60X1 FOR HG(X)7 R134a	1 ST
1211	06626	HEX.HEAD SCREW M6X10 (FIXÉ AVEC LOCTITE 243) FOR HG(X)7 R134a	4 ST
1220	05755	HEX.HEAD SCREW M16X110	4 ST

1520	08876	SET-FIXING PARTS ----- ASSEMBLY KITS -----	1 ST
2000	08498	SET-VALVE PLATE FOR HG(X)7	3 ST
	80720	SET-VALVE PLATE FOR HGX7 R134a	3 ST
2020	80116	SET-OIL PUMP	1 ST
2030	80042	SET-PISTON ø70 (OPTIMIZED)	6 ST
2040	08995	SET-PISTON-CONN.W.3 RINGS/70	6 ST
2050	80092	SET-CRANKSHAFT 70 STROKE	1 ST
2060	08398	SET-SHUT-OFF VALVE NS38	1 ST
2070	08087	SET-SHUT-OFF VALVE NS50	1 ST
2080	80093	SET-SIGHT GLASS ø60	2 ST
2090	80094	SET-GASKETS NOT SHOWN	1 ST
2100	08306	SET-CONNECTING ROD	6 ST
2110	80198	SET-REAR BEARING FLANGE	1 ST
2130	80181	SET-MOTOR 29KW Δ/YYY FOR HG(X)7/1620-4	1 ST
	80186	SET-MOTOR 29KW Δ/Y FOR HG(X)7/1620-4 FOR SPECIAL VOLTAGE	1 ST
	80182	SET-MOTOR 33KW Δ/YYY FOR HG(X)7/1620-4 S	1 ST
	80187	SET-MOTOR 33KW Δ/Y FOR HG(X)7/1620-4 S FOR SPECIAL VOLTAGE	1 ST
2160	80098	SET-TERMINAL BOARD	1 ST
2190	08102	SET-MOTOR PROT.MP10,AC 230V	1 ST
	08103	SET-MOTOR PROT.MP10,DC 24V *EX SPECIAL VERSION	1 ST
2210	08426	SET-OILS.HEAT.140W 230V AC	1 ST
	08430	SET-OILS.HEAT.140W 110-130V,SP SPECIAL VERSION	1 ST
2220	80076	SET-OIL STRAINER	1 ST
2230	80178	SET-BEARING BUSH ASSEMB.HG7 ----- ACCESSORIES ----- SU+CR+(SEA.)WC.CYLINDER COVER FOR R134a NOT ALLOWED !	1 ST
3000	08981	SET-START UNL.SU92 230V AC	1 ST
3010	03649	WC.CYLINDER COVER F.SU(BUSH)	1 ST
3020	06484	GASKET-UPPER VALVE PLATE	1 ST
3030	05454	HEX.HEAD SCREW M10X85	10 ST
3040	06276	CYLINDER HEAD SCREW M10X85	3 ST
3050	05738	LOCKING SCREW R 1/2"	2 ST
3060	05526	LOCKING SCREW R 1/2"	1 ST
3070	08953	SET-WC.CYLINDER COVER	1 ST
	80647	SET-SEA.WC.CYL.COVER	1 ST
	80646	SET-WC.CYLINDER COVER F.CR92	1 ST
	80650	SET-SEA.WC.CYL.COVER F.CR92	1 ST
	08976	SET-WC.CYLINDER COVER F.SU92	1 ST
	80649	SET-SEA.WC.CYL.COVER F.SU92	1 ST
3100	08821	SET-SU/CR92 230V AC	1 ST
3110	07848	VALVE BODY AL/LR92	1 ST
3111	05986	O-RING ø45,69X2,62 GREEN	1 ST
3112	05143	DISC ø30X16X2,0	1 ST
3113	05885	KNURLED NUT M15X1 WITH O-RING	1 ST
3120	07527	SOLENOID COIL 230V AC	1 ST
3200	08948	SET-CAP.REG.CR92 230V AC	1 ST
3250	08140	SET-BOCK-BCM 2000	1 ST
3260	06920	TAPP.SCREW W.COUNT.HEADC3.5X13	3 ST
3270	06950	BOCK-BCM 2000, AC 230V ±10%	1 ST
3275	06945	BASE PLATE SNAP-ON MOUNTING	1 ST
3280	80654	SET-BOCK-BCM 2000 /INCL.D-P	1 ST
3300	08821	SET-SU/CR92 230V AC	1 ST
3310	07848	VALVE BODY AL/LR92	2 ST
3311	05986	O-RING ø45,69X2,62 GREEN	2 ST
3312	05143	DISC ø30X16X2,0	2 ST
3313	05885	KNURLED NUT M15X1 WITH O-RING	2 ST
3320	07527	SOLENOID COIL 230V AC	2 ST
3400	80034	SET-ADDIT.VENTILA.ø312/HG7,F16	1 ST
3410	06808	VENTILATOR CPL.ø312 230/400V	1 ST
3420	06890	HOLDER F.ADDITIONAL VENTILATOR	2 ST
3440	06278	HEX.HEAD SCREW M10X80	4 ST
3450	05445	HEX.HEAD SCREW M10X25	4 ST
3460	05646	DISC B10,5	12 ST
3470	05665	SPRING WASHER B10	4 ST

3480	05630	HEX.HEAD NUT M10	4 ST
3500	08999	SET-OIL PRESSURE SAFETY SWITCH	1 ST
3510	05279	REFFLEX HOSE LINE, DN 2MM CONSISTING OF REFF.HOSE 50249 + 2x SEAL RING(7/16") 06104	1 ST
3520	05253	REFFLEX HOSE LINE, DN 2MM CONSISTING OF REFF.HOSE 50248 + 2x SEAL RING(7/16") 06104	1 ST
3600	07946	SHUT-OFF VALVE 1/4"NPTF-7/16"	1 ST
3700	80461	SET-OIL PRESS.SENSOR/MP10	1 ST
	80275	SET-OIL PRESS.SENSOR/BCM2000	1 ST
3710	60014	DELTA-P II SWITCH PART F.MP10	1 ST
	06989	INT250 SWITCH PART F.BCM 2000	1 ST
3720	50225	DELTA-P/INT250 SCREW-IN PART	1 ST
3730	05724	SEAL RING 26x20x1,5	1 ST
3750	06947	OIL TEMP.SENSOR CPL. 1/8"NPTF	1 ST
3800	08921	SET-THERM PROT.TH.1/8"NPTF	1 ST
3900	80259	SET-ADAPT.F.SHUT-OFF VALVE	1 ST
3910	80467	SET-START UNL. BOCK-ESS 106	1 ST
3990	80600	SET-EFCe A1-A6 29,0KW/45,0e WITHOUT PRESSURE TRANSDUCER FOR HG(X)7/1620-4	1 ST
	80635	SET-EFCe A1-A6 29,0KW/45,0e WITH PRESSURE TRANSDUCER FOR HG(X)7/1620-4	1 ST
	80621	SET-EFCe A1-A6 33,0KW/45,0e WITHOUT PRESSURE TRANSDUCER FOR HG(X)7/1620-4 S	1 ST
	80637	SET-EFCe A1-A6 33,0KW/45,0e WITH PRESSURE TRANSDUCER FOR HG(X)7/1620-4 S	1 ST
3991	80696	SET-HEAT-RESISTANT BACK WALL	1 ST
3999	02279	REFR.MACH.OIL SP46 / 1 LTR.CAN	1 ST
	02280	REFR.MACH.OIL SP46 / 5 LTR.CAN	1 ST
	02281	REFR.MACH.OIL SP46 /20 LTR.CAN NOT SHOWN	1 ST
	02282	ONLY FOR R22-COMPRESSORS! REFR.MACH.OIL SE55 / 1 LTR.CAN	1 ST
	02283	REFR.MACH.OIL SE55 / 5 LTR.CAN	1 ST
	02284	REFR.MACH.OIL SE55 /10 LTR.CAN NOT SHOWN ONLY FOR X-COMPRESSORS!	1 ST